



Complete with –

- Pear Push Lead and holster



Optional Extra's

- Pressure Mat
- PIR



Description:

Typically this unit would be located beside the bed for the service user to call for assistance. The 2.5m Pear Push Lead when not in use can be located into its holster on the wall beside the call point.

The large orange “staff call” button generates the next level of call indicating further assistance is required, whilst the red “alarm” button indicates an emergency situation.

The green “reset” button not only cancels a call once dealt with, but if no call is active can be used to indicate “staff presence” in the service users room for regular checks without generating a call.

Optional extra's for this unit to trigger an assistance call could be –

- ARM infrared call point upgrade to allow infrared keyfobs/pendants to be used
- A pressure mat under a rug beside the bed
- A PIR (movement sensor) for when the user walks across in front of the PIR
- An epilepsy sensor for when a Grand Mal seizure needs to be detected

Levels of Call:

- | | |
|----------------|------------------|
| ○ Patient Call | ○ Reset |
| ○ Staff Call | ○ Staff Presence |
| ○ Emergency | ○ Low Battery |
| ○ Jack Removed | |

Technical Specification:

- Reassurance LED and comfort tone
- Factory set unit identity plus fully supervised monitoring
- Conforms to BS6799 Class VI
- Effective radiated power: 10mW integral aerial, approved to MPT1344 (licence exempt)

In pursuance of a policy of continued improvement, the company reserves the right to change the design and specification without prior notice

Supplier:

Pear Push Unit

Alarm Radio Monitoring Ltd
Brunel Road
Enterprise Park
Leominster
HR6 0LX

Tel: 01568 610016
Fax: 01568 615511

E-mail:
sales@arm.uk.com

Website:
www.arm.uk.com